



Transponder Mounting Locations

All transponders must be mounted vertically with no obstruction between the transponder and the ground.

Modifieds: Must be mounted on the inner right side sheet metal surrounding the fuel cell no less than 24" behind the rear axle centerline at a height of 12" to 18" from the ground.

Sprints: Must be located on the right side behind the front torsion bar tubes on the vertical bracket at a height of 12" to 18" from the ground.

Outlaw Sprint Warriors: Must be located on the right side behind the front torsion bar tubes on the vertical bracket at a height of 12" to 18" from the ground.

Late Models: Must be mounted 12" back from the center of axle tube to center of transponder on left side frame at a height of 12" to 18" from the ground.

Stock Cars: Must be mounted on the right rear frame rail of the chassis 12" behind the rear axle tube at a height of 12" to 18" from the ground.

Mod Lites: Must be mounted on the inner right side chassis frame in a range of 9" to 12" behind the rear axle center line at a height of 12" to 18" from the ground.

Mini Stocks: No transponders required.